


Trotec PrinterDriver Installer

Premises:

- The Trotec PrinterDriver Installer <TrDriverInstaller.exe>, deletes previous installed printers and drivers in order to make an update to the latest Trotec PrinterDriver version.
- Please ensure that no other applications are running during setup process.
- In order to install the latest Trotec PrinterDriver version you need administrator rights.
- The PC will be rebooted automatically after installation process has finished.

Installation- Process

1. Download the compressed file <Trotec PrinterDriver v8.0.5.2.zip> from Virtual Service Technician site.
2. Extract the Zip folder to your local drive.
3. Please note that some Zip programs do not extract the containing folder structure of the Zip file per default. Ensure that after the file have been extraced, the directory structure is as shown below.



4. Run <TrDriverInstaller.exe>



With option **(1)** the latest printer driver version is installed automatically. Therefore previous installed printers and printer drivers v8.0.x.y are deleted automatically.

With option **(2)** the currently installed printer and printer drivers based on v8.0.x.y are deleted.

5. After the PC has rebooted the new printer driver is ready for use.